

# **AM CHAMPION**BATTERY SPRAYER





BEFORE OPERATING THIS MACHINE, PLEASE READ THESE INSTRUCTIONS CAREFULLY

- 1. Each time after using this sprayer, it must be charged to maintain inside power and to avoid short working life
  2. When doing charge or discharge, please assure that you have switched off the power to avoid to wasting electricity.
  3. After using sprayer. It should be recharged, If not using the sprayer for long time, please charge the battery approx. once in a month to retain life-span of battery.
  4. After using sprayer. Please keep outside and inside of sprayer clean.
  5. Keep the sprayer in the shady place. Don't store the sprayer under direct sunlight.
  - 6. Please keep no residue of insecticide, fertilizer or herbicide at bottom of tank, keep bottom dry so as to avoid corrosion.

### **SAFETY WARNING**

If you are using the sprayer with hazardous or poisonous liquid, use only with directions supplied by the manufacturer of the hazardous or poisonous liquid. Please clean the sprayer thoroughly after use.

**Note:** Please clean tank inside by clear water after spraying each time. Please using filter when put into water. **STORE:** Please clean the pump, then charge 10-15 hours, keep it at day shady place.

**WARNING:** Don't let battery without power, otherwise it can't charge next time. As battery with self discharge function, please recharge after two or three months.

2 4 4 4 5

GRIFFATE AGRIFFATE

Economy

AGRIFIATE

Admini Power - Super Economy

E A

### **EXAMINATION**

AGRIFIATE

AGRIFIATE

AGRIFIATE

Problem	Cause	Remedies  Charge or check plug  Pause then continue spraying after cooling down  Clean nozzle Check hose tighten, release air	
DC Motor Doesn't work     Automatic stop during spraying	No Power or loose plug		
	Overheat damaged intelligent controller		
3. No water Sprayers, Nozzle	Jammed Nozzle Air in hose		
Instable water Pressure	Jammed Pump Broken hose	Check pump clean eye winker Change new one	
Lower Pressure and saller Smaller flux	Jammed filter in hose Jammed filter in sprayer switch Lower Voltage	Clean filter Clean Filter Change new one	
Leakage in tie – in	Loose tie-in Broken O ring	Tighten Screw Check new one	
Sprayer doesn't work well	Jammed nozzle Broken Sprayer core	Clean eye winker Change new One	
Pump Motor starts then cut sometimer when stop spray	Eye winker in the Switch Rubber Seal Hose Leakage at the pump	Open and clean Tighten Tighten	

### **TECHNICAL SPECIFICATION**

Model	AM CHAMPION
Name	Battery Sprayer
Tank Capacity	16L
Pump Rate	3.6 L
Battery	8AH with regulator
Lance	Telescopic SS

**DIAGRAM OF AM CHAMPION - BATTERY SPRAYER** AGRÎMATE BATTERY SPRAYER <u>20</u> <u>5</u> <u>15</u> <u>16</u> 4 THATE

## **AM CHAMPION SPRAYER - SPARE PARTS**

AGRIMATE

AGRIFIATE

Part No.	Description
AM-CHAMPION-01	Tank cap
AM-CHAMPION-02	Strainer
AM-CHAMPION-03	Tank
AM-CHAMPION-04	Backrest
AM-CHAMPION-05	Hose
AM-CHAMPION-06	Inner filter
AM-CHAMPION-07	Elbow
AM-CHAMPION-08	Auto pump
AM-CHAMPION-09	8 holes nozzle
AM-CHAMPION-9.1	Fan nozzle
AM-CHAMPION-9.2	4 holes nozzle
AM-CHAMPION-9.3	Adjustable nozzle
AM-CHAMPION-10	Extensive ss lance
AM-CHAMPION-11	1.3A Charger
AM-CHAMPION-12	Regulator
AM-CHAMPION-13	On/off switch
AM-CHAMPION-14	Charging socket
AM-CHAMPION-15	Volt meter
AM-CHAMPION-16	12V/8AH battery
AM-CHAMPION-17	Bottom plate
AM-CHAMPION-18	Belt
AM-CHAMPION-19	Side small cap
AM-CHAMPION-20	Trigger
AM-CHAMPION-21	Lance clip
AM-CHAMPION-22	Battery clip

## **SPARE PARTS DIAGRAM & LIST OF AM CHAMPION**































# **SPARE PARTS DIAGRAM & LIST OF AM CHAMPION**



AGRIMATE





AGRIMATE













AGRI











### **INSPECTION & MAINTENANCE**

For safety use, make sure the machine is cleaned every three-months. Before working, make sure to inspect the filter and the nozzle, and ensure there is no impurity. After working, make sure there is no water in the pump and the hose.

If the machine needs to be repaired in the guarantee period, please return the machine to the shop. You need to provide the certificate of purchase in order to repair or get the substitute.

Before Packing, the machine should be cleaned, then use closed packaging, packaging should be firm. Store the machine in dry place.

For transportation safety. The machine should comply with ISTA.




Meaning of crossed - out wheeled dustbin:

Do not dispose of electrical machines as unsorted municipal waste, use separate collection facilities.

If electrical machines are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

When replacing old machines with new ones, the retailer is legally obligated to take back your old machine for disposals at least free of charge.



1. LIMITED WARRANTY PERIOD: For a period of six months from the date of Sale / delivery of the product which ever is earlier. 2. LIMITED WARRANTY OBLIGATION: Replacement of defective part(s) by authorized dealer are free of charges. If found defective by reasons of defective material / poor workmanship, parts will be replaced and there will be no value re-imbursement. 3. TERMS & CONDITIONS: a. Claims under warranty will be accepted on submission of Warranty Card duly filled and stamped by authorized dealer together with the original purchase document. b. Shipping / transportation / Incidental charges incurred in replacing defective parts under warranty shall be borne by the purchaser.

#### WARRANTY null & void if

- (i) Lack of maintenance, (ii) Incorrect use of the machine or tampering, (iii) Use of non-genuine spare parts, (iv) Usage of acids, solvents, or any flammable materials, (v) Non-usage of filter water / coler water / soft water & using water above 40°C temperature, (vi) While using the pressure washers to draw water which is contaminated with dust & solvents (eg. paint thinners, gasoline, oil, etc.), (vii) Repair done by unauthorized service people, (viii) Those parts subject to wear & tear due to normal operations and plastic parts, rubber items etc., (ix) Loose connections, faulty electrical fixtures & fluctuations in power supply.
- 4. Should any failure occur during or after the warranty period, customer does not have the right to interrupt payment / price discount.
- 5. Incidental or consequential damages like inconvenience commercial loss, loss of tie, mental agony etc.
- 6. Loss of any nature due to operation or non-operation is not covered under warranty.
- 7. All free service are at Dealer's service point only.
- 8. Warranty ceases if service is not done periodically.
- 9. The attached card should be completed and returned to Ratnagiri Impex Pvt. Ltd. for registration immediately after sale / delivery.
- 10. The warranty is void unless you register the warranty card with Ratnagiri Impex Pvt. Ltd.
- 11. The decision of Ratnagiri Impex Pvt. Ltd., in settling the warranty is final in all respects.
- 12. All disputes are subject to Bangalore Courts Jurisdiction
- 1. LIMITED WARRANTY PERIOD: For a period of six months from the date of Sale / delivery of the product which ever is earlier. 2. LIMITED WARRANTY OBLIGATION: Replacement of defective part(s) by authorized dealer are free of charges. If found defective by reasons of defective material / poor workmanship, parts will be replaced and there will be no value re-imbursement. 3. TERMS & CONDITIONS: a. Claims under warranty will be accepted on submission of Warranty Card duly filled and stamped by authorized dealer together with the original purchase document.: b. Shipping / transportation / Incidental charges incurred in replacing defective parts under warranty shall be borne by the purchaser.

#### WARRANTY null & void if

- (i) Lack of maintenance, (ii) Incorrect use of the machine or tampering, (iii) Use of non-genuine spare parts, (iv) Usage of acids, solvents, or any flammable materials, (v) Non-usage of filter water / clear water / soft water & using water above 40°C temperature, (vi) While using the pressure washers to draw water which is contaminated with dust & solvents (eg. paint thinners, gasoline, oil, etc.), (vii) Repair done by unauthorized service people, (viii) Those parts subject to wear & tear due to normal operations and plastic parts, rubber items etc, (ix) Loose connections, faulty electrical fixtures & fluctuations in power supply.
- 4. Should any failure occur during or after the warranty period, customer does not have the right to interrupt payment / price discount.
- 5. Incidental or consequential damages like inconvenience commercial loss, loss of tie, mental agony etc.
- 6. Loss of any nature due to operation or non-operation is not covered under warranty.
- 7. All free service are at Dealer's service point only.
- 8. Warranty ceases if service is not done periodically.
- 9. The attached card should be completed and returned to Ratnagiri Impex Pvt. Ltd. for registration immediately after sale / delivery.
- 10. The warranty is void unless you register the warranty card with Ratnagiri Impex Pvt. Ltd.
- 11. The decision of Ratnagiri Impex Pvt. Ltd., in settling the warranty is final in all respects.
- 12. All disputes are subject to Bangalore Courts Jurisdiction
- 1. LIMITED WARRANTY PERIOD: For a period of six months from the date of Sale / delivery of the product which ever is earlier. 2. LIMITED WARRANTY OBLIGATION: Replacement of defective part(s) by authorized dealer are free of charges. If found defective by reasons of defective material / poor workmanship, parts will be replaced and there will be no value re-imbursement. 3. TERMS & CONDITIONS: a. Claims under warranty will be accepted on submission of Warranty Card duly filled and stamped by authorized dealer together with the original purchase document.: b. Shipping / transportation / Incidental charges incurred in replacing defective parts under warranty shall be borne by the purchaser.

### WARRANTY null & void if

- (i) Lack of maintenance, (ii) Incorrect use of the machine or tampering, (iii) Use of non-genuine spare parts, (iv) Usage of acids, solvents, or any flammable materials, (v) Non-usage of filter water / clear water / soft water & using water above 40°C temperature, (vi) While using the pressure washers to draw water which is contaminated with dust & solvents (eg. paint thinners, gasoline, oil, etc.), (vii) Repair done by unauthorized service people, (viii) Those parts subject to wear & tear due to normal operations and plastic parts, rubber items etc, (ix) Loose connections, faulty electrical fixtures & fluctuations in power supply.
- 4. Should any failure occur during or after the warranty period, customer does not have the right to interrupt payment / price discount.
- 5. Incidental or consequential damages like inconvenience commercial loss, loss of tie, mental agony etc.
- 6. Loss of any nature due to operation or non-operation is not covered under warranty.
- 7. All free service are at Dealer's service point only.
- 8. Warranty ceases if service is not done periodically.
- 9. The attached card should be completed and returned to Ratnagiri Impex Pvt. Ltd. for registration immediately after sale / delivery.
- 10. The warranty is void unless you register the warranty card with Ratnagiri Impex Pvt. Ltd.
- 11. The decision of Ratnagiri Impex Pvt. Ltd., in settling the warranty is final in all respects.
- 12. All disputes are subject to Bangalore Courts Jurisdiction

Maximum Power - Super Economy	Maximum Power - Super Economy Maximum Power - Super Economy	Maximum Power - Super Economy Maximum Power - Super Economy	Maximum Power - Super Economy	Maximum Por
AGA	Impex	CERTIFIED CO	01-2015 MPANY	AGF
Maximum		0Days / 30 hrs (Which ever is earlier)		Maximum
G	Model AM-CHAMPION BATTERY SPRAYER	Serial Number	ON	8
AGE TO	PDI Date	Purchase bill no. Date	JUG	AG T
Maxim	Dibate	Tuchase birrio.	50	Maxim
4	Service No.		SERVIC	
Maximum Pov			S	Maximum Po
The state of the s			#	William
9	Dealer's Office Seal		ND ND	
Maximum Pov			Y AND	Maximum Po
1			WARRANT	141000
G	Dealer Signature	Customer Signature	NR.	
Maximum Pov		entire satisfaction without any labour charges. Only consumables were charg	ged.	Maximum Po
Memory	agriculture I hortic	culture   sericulture   plantations   forestry   garden   health care		
Maximum Pov	2nd Fre	ee Service Coupon		Maximum Por
	And Andrew Control of the Control of	ISO 90 CERTIFIED CC	01-2015 IMPANY	
4	FREE SERVICE COUPON (6	ODays / 60 hrs (Which ever is earlier)		
Maximum Pov	Model	Serial Number	Z	Maximum Por
	AM-CHAMPION BATTERY SPRAYER		FREE SERVICE COUPON	
4	PDI Date	Purchase bill no. Date	00	
Maximum Pov	Service No.		100	Maximum Po
110000	CONTROL NO.		SER	14100
4			Ш	
AGIT Maximum Pov	2 1 / 2% 2 1		E 0	Maximum Po
	Dealer's Office Seal		A	1444
G.			À.	
AG FI			marranty and	Maximum Po
Monarca	Dealer Signature	Customer Signatureentire satisfaction without any labour charges. Only consumables were charge	XA	With
G	<b>*</b>	culture   sericulture   plantations   forestry   garden   health care		
AGE	Maximum Pawer - Super Economy	antare i seneultare i prantations i forestry i garden i neutri care		AGI
Maxim	2rd Fro	e Service Coupon		-8
G	ratnagiri	ISO 90	01-2015	4
Maximum Pov	FREE SERVICE COUPON (9)	0 Days /120hrs (Which ever is earlier)	IVII AIVI	Maximum Por
	Model	Serial Number	Z	
9	AM-CHAMPION BATTERY SPRAYER		JPO	
AG FI	PDI Date	Purchase bill no. Date	100	Maximum Po
A STATE OF THE STA	Our ha Na		<u>G</u>	14100
· ·	Service No.		EBV	4
AGIT Hayimum Pov			H.	AG T
Nida	V (0		Œ	Maxim
6	Dealer's Office Seal		AND DAVE	-
AGR			È	AG T
Maximo			BAN	Maximo
G	Dealer Signature	Customer Signature	pp ::: Warranty and free service	1
Maximum Pov		entire satisfaction without any labour charges. Only consumables were charg	ed. S	AG T
H (Mariana)	AGRIMATE agriculture   hortic	culture   sericulture   plantations   forestry   garden   health care		Museum
		AUTHORES AGRICATE		
		AURITAGE  POWER - Super Economy  POWER - Super Economy		



- Always read the instruction manual supplied along with the equipments and understand the correct installation and operating procedures before attempting to use the equipments.
- It is important to use the personal protection equipments such as head helmet with visor, ear defenders, goggles, safety gloves, cut resistant shoes, trousers and jackets while operating potentially dangerous machines.
- Avoid untrained persons using the equipments. Children must not be allowed to handle these
  equipments.
- Always use genuine spares and accessories in repairs and usage to derive maximum life of the equipments.
- Always keep the equipments in good working condition to minimise loss of output as well as
  to reduce the pollution and save the environment.
- Do not use the machine within range of persons unless they wear protective clothing.
- Do not operate the machine when fatigued or under the influence of alcohol or drugs.
- When the machine is running, please maintain a constant water supply. Without water circulation will damage the sealing rings of the machine.
- For more query kindly contact for our Service Center/Dealer/ franchise

# **Agrimate Army For Pest Control**

ANY WHERE - ANY TIME - ANY CROP



Imported & Marketed by RATNAGIRI IMPEX PVT LTD Annapurna House, #1/1G, 7th Cross, New Guddadahalli Mysore Road, Bangalore-560 026 Customer Care: 1800-425-3036





email: info@ratnagiriimpex.com